

Spectralink Phone Quick Reference Guide

Purpose

The purpose of this guide is to provide the Spectralink phone user with operation instructions on viewing and deleting Code Alert messages.

Messaging Operation

The handset will store up to 9 messages in the queue at any one time. The order of the messages is shown by the numbers across the top of the screen.

When a handset responds to the Code Alert message, the user is prompted with “New Message Press Start”. If the user is in a voice call, a short tone will play.

Press the **Start Call** key to display the message

- Press **>** to scroll through message (if message is larger than one screen).
- Press **<** to scroll back through message (if message is larger than one screen).
- Press **7** to view previous message
- Press **9** to view next message
- Press **4** to delete the current message. Press **1** to confirm delete or **2** to cancel delete.
- Press **FCN + 4** to delete all messages. Press **1** to confirm delete or **2** to cancel delete.

NOTE: Only the keys listed above have functionality with the Code Alert System.

If the mail envelope is displayed, the handset has a Code Alert message waiting to be displayed. The user may enter a messaging session by pressing **Start Call** followed by **FCN + 8** to display Code Alert messages.



