



**Push Button
Call Station**
(in alarm)
9600-0377



**Nurse Call
Cord Station**
(standard)
9600-0388



**Pull Cord
Call Station**
(standard)
9600-0305



**Pull Cord
Call Station**
(with Check-in,
in alarm)
9600-0355

Description

These wall-mounted call stations feature a slim, discreet profile and provide visual confirmation that a call has been placed and received.

- LED blinks on the device, giving the resident peace of mind the call was placed; long flash confirms call was received at the central station
- "Assistance Required" alarm appears in software's Event List when a resident activates
- Alarm must be reset at the device, ensuring every call gets a response

Push Button Call Station

- Red button offers high contrast visibility for residents with poor eyesight
- Device is frequently used in bathrooms and common areas

Nurse Call Cord Station

- Compatible with standard 1/4-inch normally open nurse call cords
- The 90° side-angle connection helps prevent accidental removal; device also sends an alert if cord is removed
- Device is frequently used at residents' bedside

Pull Cord Call Station

- "HELP" flag appears when cord is pulled
- Optional check-in button records non-alarm events, such as resident or staff check-in, or a time log
- Device is frequently used in resident rooms and common areas

Features

- Modern appearance blends into the community for a home-like environment
- Wireless installation makes it easy to add or move devices as your facility needs change
- Fully supervised system alerts you to low batteries and device failures within 90 seconds
- Mounts anywhere on the wall; no need for a surface-mount or back box
- Push Button and Pull Cord stations are water resistant and suitable for use near showers and tubs
- Call data can be sent to optional communication devices such as pagers, Quick Look™ LED displays and/or wireless phones
- Conforms to UL 1069 Edition 7 for Wireless Signaling and Nurse Call Devices
- Proven reliability from a trusted brand

