

Wander Management Solution—Discreet, Dignified and Restraint-free

A secure environment is crucial to your residents and their families. **CODE ALERT® Wander Management Solution** keeps residents at risk of wandering safe, reducing the risk of elopement, injury and liability. Residents are monitored via wireless wrist or ankle-style transmitters that promote mobility in a homelike, barrier-free environment, while allowing visitors and staff to move easily throughout the community.

- Fully-supervised system alerts staff to potential issues before an elopement occurs.
- Antenna detects when a transmitter is in close proximity of a monitored exit; system arms the door and instantly notifies caregivers; alarm sounds if an attempt is made to open a locked door.
- Computer-based reports enable improved quality of care and staff efficiency.

Two Options: Choose the Protection That's Right for Your Community

1. Perimeter Alarm Security

Model T30 is an “always armed” non-PC-based system that provides 24/7 exit monitoring:

- Alarm sounds when a locked door is opened.
- Keypads at exits enable alarm bypass with security code.

2. Transmitter-based Protection

Model T70 and T80 controllers are transmitter-based, with antennas to monitor exits:

- Elevators deactivate to keep residents safe on their designated floor.
- Escort feature enables residents to leave an area for a set time without an alarm sounding.
- For added flexibility, choose from transmitters featuring various battery lives.



CODE WATCH®
Customization

Quick Response® Plus Wireless Call Solution

When your residents need assistance, you want them to know help is on the way. The **Quick Response® Plus Wireless Call Solution** gives residents peace of mind, knowing they need only push a button or pull a cord to call for help. UL 2560 certification ensures quality, safety and performance. A scalable, cost-effective wireless call solution that is expandable, to meet your needs for years to come.

Reliable & Feature-Rich Safety Solution

- Smart ID technology identifies both the resident and their location as soon as the pendant button is pushed, ensuring a fast response.
- Discreet, pendant-style wireless call devices promote mobility, with coverage extending outdoors for safety in gardens, courtyards, and patio areas.
- Flexible alerting options and escalation paths improve caregiver response times. Alerts can be received at a central computer station and also on a wide range of mobile devices; silent notification option is conducive to a peaceful, homelike atmosphere.
- Data stored within easy-to-use software enables analysis that can improve care, enhance staff efficiency, and reduce liability.

Multiple Call Options

- **Pendant:** Worn pendant-style, strapped to the wrist, or attached to clothing.
- **Pull Cord Call Station:** Stationary call device frequently located in restrooms and common areas.
- **Push Button Call Station:** Stationary call station from which help can be summoned with the push of a button.
- **Call Cord:** Allows residents to call for assistance from their bedside.



Wired Call Solution

Certified to UL 1069, Edition 7 Standards (now mandatory for hospitals and skilled nursing communities in many states), helping to ensure:

- *Continuous, reliable operation and long product lifetimes for cost effectiveness.*
- *High durability with tested impact and vibration resistance.*
- *Designed for high humidity and oxygen-rich environments (including flame retardancy).*

Signaling and Receiving Testing

Compliance with UL 1069, Edition 7 ensures that any call signal that doesn't get through on a first attempt is continuously transmitted until it reaches notification devices. In order to receive UL 1069 certification, the signaling/receiving function on our wired call solution has been tested more than 100,000 times.



HOW IT WORKS

1. A resident calls for assistance using a call station or mobile pendant.
2. System components receive, process and route the signal to a caregiver.
3. Caregiver's notification device receives interpreted signal and directs them to the appropriate resident.



Touchpad Exit Controller for Wander Management

A central component of our transmitter-based security or continuous perimeter monitoring system, this responsive 10-digit touchpad provides the latest in discreet exit monitoring. Available in three models.

There When You Need It, Discreet When You Don't

- *White LED backlight illuminates touchpad when pressed, turns off when not in use.*
- *Silence alarms or bypass a door by entering a code on the touchpad - alarms are forwarded to a central computer station (can also be sent to pagers or mobile devices).*
- *10-digit touchpad enables staff to create a more secure code that is less easily compromised.*

RFT CARES® App

Allows caregivers to receive, acknowledge and classify alarms and scheduled events on mobile devices. Multiple alerts or events appear in the applications queue, allowing caregivers to coordinate responses using the "I Got It" feature to claim an alert. Once resolved, alerts can be classified right from the app, enabling tracking of alert trends and services delivered, over time.

- *Works with existing Wi-Fi network (cellphone service and/or Internet access not required).*
- *Available with CODE ALERT software v9.5 or later.*

Android Wear compatible—view and clear alarms directly from your wrist. Leave the phone in your pocket! **iOS version now available!**

